



This release provides updated Mac OS X system Device Drivers
for your XONE:23C soundcard

Xone Product **XONE:23C**
Device Driver (OS X) **v3.3.2** [Xone 23C_3.3.2.dmg]

Supported OS: Mac OS X 10.11 [El Capitan]
 Mac OS X 10.10 [Yosemite]
 Mac OS X 10.9 [Mavericks]
 Mac OS X 10.8 [Mountain Lion]

v3.2.2 Device Drivers

Delivers support for Mac OS X 10.11 [El Capitan]
Improves audio streaming and stability

See p.2 for software changelog detail

Installing XONE Device Software

PLEASE FOLLOW INSTALL & UPDATE INSTRUCTIONS CAREFULLY

- Install new v3.3.2 OS X system Device Drivers

! DO NOT interrupt pow supply to computer.

Ensure your computer is connected to a mains power supply and configured with energy/power saving options OFF:

- 🔗 Go to: *System Preferences* > *Energy Saver*
- 🔗 Set "Computer Sleep" to: "Never"
- 🔗 Set "Display Sleep" to: "Never"
- 🔗 Uncheck box: "Put hard disks to sleeps when possible"

Step 1: Install Device Drivers

- ① Please ensure you download & install the correct Device Drivers for your operating system
- !** Ensure your XONE mixer is **disconnected** from the host Mac and powered **OFF**
- 🔗 Expand the .zip bundle and open the **Xone 23C_3.3.2.dmg** file
- 🔗 Double-click on **Xone 23C_3.3.2.pkg** to run the driver installer
- Follow the on-screen instructions.
You will be guided through the steps necessary to install this software.
- 🔗 After completing the driver installation, **RESTART** the Mac.

