



MPX16

Latest Firmware Version: v1.0.18

Release Date: January 15, 2015

Firmware Update Instructions

Warning: During the following steps, do **not** remove the SD card or power MPX16 off. Doing so could damage it.

1. Unzip the contents of the **.zip** file to your Desktop.
2. Place the **MPX16UPD.DAT** file on the root (main) directory of an SD card (formatted to a FAT32 file system).
3. Insert the SD card into MPX16's **SD card slot**.
4. On your MPX16, press and hold both **Select +** and **Pad Edit**, power MPX16 on, and then release the buttons.
5. When prompted, press **Enter**. The unit will begin the firmware update.
6. Allow the update process to complete.
7. When the display shows **Complete**, power-cycle MPX16 (power it off then on again).
8. Congratulations! Your MPX16 now has the newest firmware!

Changes Since Firmware Version 1.0.7

- Adds a fixed-velocity setting to allow Full Level feature.
- Fixes minor bugs.

Technical Support

For additional help, visit akaipro.com/support.