

P70 Digital Media Player & Controller

- CD/CD-R/CD-RW music, Mp3/Wav music playback
- 2 USB sockets for external USB device support
- All control elements are MIDI compatible (PC/Mac)
- Four Independent 5-seconds Sample Bank
- Multi-functional Touch Sensitive Jog Wheel with 9 different lighting modes
- Innovative Active Cue Point (A.C.P.) indicator system helps DJs to find the cue point and juggling
- Build-in 3 digital effects: Echo, Flanger, Filter
- Auto Loop function with 11 selectable bar lengths
- LINKUP technology allow you to link two or more P70s together
- VOXOA TUNEBOX music database builder software



Specification

Power: AC100-240V, 50/60Hz, 19W
 Weight: 2.42kg
 Size: 296 (W) X 218 (D) X 103.5 (H) mm
 Media: CD, CD-R, CD-RW/CD Music and MP3/Wav format
 Frequency Response:
 CD: Typical 17-20KHz +/-0.4dB, Limit 17-20KHz +/-1dB @0dB OUTPUT
 USB1.2: Typical 17-16KHz +/-0.2dB, Limit 17-16KHz +/-1dB
 De-Emphasis: CD Typical -20dB +/-0.2dB, Limit -20dB +/-1dB 16KHz-20dB
 Channel Separation: CD, USB1.2 Typical 91dB 85dB, Limit 1KHz, 0dB
 THD+N: CD: Typical 0.006%, Limit 0.01% @1KHz, 0dB
 USB1.2: Typical 0.007%, Limit 0.01% @ 1KHz, 0dB
 S/N Ratio: Typical 126dB, Limit 90dB @ 1KHz, 0dB
 Output: RCA, Digital Output, headphone output



Features

1. Multi-format Music Playback

The P70 can read, display and play MP3 files written to CD-Rs providing DJs with the ability to store more music on a single media or for extended playback time. P70 also can support external USB mass storage devices and play MP3/Wav format music.



2. A.C.P: Active Cue Point

P70's innovative design gives DJs the ability to control up to five cues including one normal cue and four hot cues. DJs can use these cues to perform creatively. The Active Cue Point (A.C.P) is a visual indicator located in the 12 o'clock position of the jog wheel. It helps DJs find the cue point and scratch. Every time DJs activate a cue, the start point of the cue instantly shifts to the 12 o'clock position. The cue always begins at the 12 o'clock position, and the lighting ring can indicate this with a blue light on the position. DJs get an intuitive reminder and convenient operation, both visually and operationally.



3. MIDI Interface Controller (PC/MAC)

In this new era of DJing, more and more DJs utilize computer and DJ software for their performances. In order to satisfy DJs requirement, the P70 is also designed to interface and control a variety of popular DJ software applications that support USB MIDI interface. DJs can assign virtually every button on the control panel to trigger functions of various DJ software programs. Moreover, The A/B deck switch design allows control of from one to two play decks.



4. Memo Points with 4 Trigger Pads

P70 can help you locate music via four memory points per song. Memory points can become hot cues or loops. From CD/MP3 disks, P70 can save 2048 memory points to be recalled later when a track is cued in from the CD drive. Memory points for USB devices are limited only by your USB memory capacity. This memory function can be used like a mini sampler for vocal, melody, or beats, adding that touch of creativity to any DJ set.



5. Link Up Two P70s

With VOXOA's new LINKUP technology, you can link two P70s via a USB cable to share a single external USB mass storage device from just one player. DJs don't need to have several USB storage devices for different players and can easily manage music resources from one storage device.



6. VOXOA TUNEBOX database builder software

Free downloadable VOXOA TUNEBOX software makes reading and searching files much quicker and easier. The VOXOA TUNEBOX scans all of music files in your USB mass storage devices and then creates a database file by which you can quickly locate files in your music library.



7. 3 DSP Digital Sound Effects

The P70 supplies the DJ with three different types of on-board effects, including ECHO, FLANGER, and FILTER, to enhance creativity in performances. Also, effect parameters Time and Depth can be adjusted independently via the jog wheel.



8. Vinyl Speed Start/Break Adjustment

To simulate the sounds of vinyl, P70 has vinyl mode. Two separate control knobs allow you to start and stop the music with the same effects you hear on vinyl -- the sound of the motor picking up speed and the sound of the motor slowing to a stop.



Other Functions

- Cue Play function can back to cue and play instantly
- Auto cue function cues track to start of music
- Seamless loop function / reloop function
- Relay play
- Fader Start
- Auto Loop function with 11 selectable bar lengths
- Pitch range ±5%, ±10%, ±16% and ±100%
- Key Lock
- 3 modes for jog wheel: Normal CDJ, Scratch, Cue Scratch
- Large extra bright display
- Digital S-POF output
- Headphone output with volume control

*All specifications and appearances are subject to change without notice. VOXOA reserves the rights to change the design for products improvement.

