INSTALLING THE DRIVER—WINDOWS

Downloading the Drivers

Your ZED-R / GS-R has firmware installed already, but in order for your Windows computer to be able to communicate with the FireWire device you will need to load some Drivers onto your computer.

IT IS VERY IMPORTANT ANY PREVIOUS DRIVERS FOR BOTH DESKS ARE UNINSTALLED FIRST.

To uninstall go to Start/All Programs/Allen and Heath Ltd/Uninstall

Driver 3.5.5 and above now works for both desks, so no need for separate drivers.

The installer software is available on the Allen & Heath website at:

http://www.allen-heath.com/UK/Downloads/Pages/Software.aspx

Microsoft Windows XP, Vista, W7 Installation:

Make sure that the ZED-R / GS-R is **NOT** connected to your computer.

Save the installer program to your computer desktop.

Run the Installer program by double clicking it

(**the ZED-R / GS-R should still be disconnected**),

following the prompts

Run, Next, Next, Next, Install, Continue Anyway, Finish.

Re-start your computer.

Connect the FireWire lead from your ZED-R / GS-R to the FireWire Host port on your computer and power on the ZED-R / GS-R.

Vista / 07 is now set up and ready to go. See Below.

Microsoft Windows XP installation:

You will be asked if Windows can connect to Windows Update to search for software—click No, not this time…..

Click Next

The Hardware Wizard will ask to install automatically or from a specific location—click automatically…..

Click Next

You may get a message or warning about Windows logo compatibility, click Continue Anyway.

Click Finish.

The process will now happen twice more for GS-R firmware and only once for ZED-R firmware for the MIDI driver, repeat the steps taken for Microsoft Windows XP installation above.

Click Finish to complete Install.